

Admin



BLTouch Not Working

gCreate · Apr 15, 2020 · None

Watch [More]



gCreate
Administrator
Staff member

Apr 15, 2020

#1

Having BLTouch problems?

If your BLTouch **doesn't light up** or **trigger when the printer is turned on**, but the rest of the printer seems fine (Motors and fans all work), it most likely isn't a bad BLTouch


If your printer had a seriously bad print that caked your hotend, there is a possibility that the BLTouch shorted out some of the electrical components of the printer. This means that the Arduino's built-in 5v regulator could have burned out, or a trace line in the electronics case's rear PCB connector board burned out.

Here are some possible fixes to this problem:

- Replace the electronics case rear PCB connector board
- Replace Arduino

Report Edit History Delete IP Change date Change author

Like Quote Reply



Write your reply...

Attach files

Post reply

Preview

Share: [f](#) [t](#) [g](#) [p](#) [t](#) [w](#) [e](#) [s](#)

Home

Forums

gCreate Knowledge Base and Support

gMax 2 Troubleshooting and Maintenance



gCreate Offices


361 Stagg St

Brooklyn, NY 11206

[gCreate Website](#)

[gCreate Store](#)

[gCreate 3D Print Services](#)



[Contact us](#) [Terms and rules](#) [Help](#) [Home](#) [RSS](#)