

Install the new plugs on the hotend power wire coming from the electronics box. Make sure to have black and red wires on the extruder 1 plug and green and white wires on the extruder 2 plug.







After the J-head hotends have been disconnected, you are going to need to remove the M5x40mm Bolts holding them in place. Make sure to save aluminum plate at the top of the J-head hotends. These plates will be needed to install the E3D hotends.

BLTouch Bracket



Once you have the J-head hotends removed, it is time to change the BLTouch mounting bracket



After you have removed the bracket, make sure to save all hardware used to mount the BLTouch to the bracket. You will need these to mount the BLTouch to the new bracket that was sent with the kit. Notice that you need to have the spring sandwiched between the two washers.



The new bracket has locknuts installed to help prevent the BLTouch from loosing its height. You are going to want to tighten the screws down until there is about 1/4" gap between the top of the BLTouch and the bottom of the bracket.

E3D Installation





Now you can start installing your new E3D hotends. Make sure to insert the provided PTFE tubing into the E3D. You may have to pull PTFE tubing out of your extruder from the J-head hotends. There is no need to save the old PTFE tubing. You will also be using the metal brackets that were taken off of the J-head hotends. It is easiest to insert the M5x40 mm bolts in the holes before putting the bracket on the the E3D.



You may have to remove the left E3D's active cooling fan to install.



After the E3D's have been installed, you will want to install the BLTouch with its new bracket. The BLTouch no longer needs to be installed at the same time as the LED light cover. This helps cut down on the amount of adjusting that may need to be done to the BLTouch. After the BLTouch is installed, it is time to install the new fan shroud. The new fan shroud will sit lower than the original fan shroud since the E3D hotends are longer than J-heads.





Now that the hotends are installed, you can start to wire everything up. There is a special spliter cable that is used to connect both active cooling fans for the E3D. Use the supplied pins to connect the active cooling fans to the spliter. Once this is connected, you can use a piece of tape and a zip tie to hold it together. After the active cooling fan is all taken care of, you will need to connect the thermistors in the correct

position. The left extruder is number 1 and the right is number 2





Now you can start to zip tie the wires together to prevent them from getting tangled or randomly pulled. You can also connect the Extruder power wire plugs and zip tie them to the rear of the extruder



Once all of the wires have been connected, it is time to install the LED Cover. The new cover that was sent with your upgrade kit does not need to be screwed on anymore. The cover has a piece that slides over the RJ-45 mounting screws and holds it in place.

Final Steps

After everything is installed, you are going to have to update your printers firmware. Instructions for this can be found in the resources tab of the forum. You can also find a YouTube video on updating the firmware here.

Attachments





gCreate Offices

361 Stagg St

Brooklyn, NY 11206

gCreate Website gCreate Store gCreate 3D Print Services



Contact us Terms and rules Help Home 🔈

Forum software by XenForo™ ©2010-2017 XenForo Ltd. // XenForo theme by xenfocus