



Parts Needed

- (2) M3x6 mm Socket Head
- (2) M3x8 mm Socket Head
- (4) M3 Nuts
- (2) M5x15 mm Low Profile Socket head
- (2) M5 Lock Nut
- (1) Metal Case
- (1) SSR
- (1) Rubber Grommet
- (1) Male Socket
- (1) Female Socket
- (1) 2 Pin Green Connector

Steps

- 1. Tap (8) side holes with M3 tap
- 2. Install power sockets with M3 screws. Secure with M3 nut and loctite.
- 3. Install SSR with M5 x 15 flat head and include ground wire with insulated eye connector





Parts Needed

(2) Wire Set From Wiring Diagram

Steps

- 1. Connect black ground wire first. Route under power sockets from relay to wall plug power receptacle
- 2. Install Green/Blue thermistor wire.
- 3. Install red wire to terminal #3 and install yellow wire to terminal #4
- 4. Install short black wire terminal #2 to wall plug power receptacle
- 5. Connect long red wire from terminal #1 to heated bed plug receptacle
- 6. Connect short red wire from heat bed power receptacle to wall plug power receptacle
- 7. Add hot glue to sides of heated bed power receptacle
- 8. Install cover with (8) M3x6mm Socket Head